# Natural Color Extraction Method for Sorrel (Hibiscus sabdariffa)

#### Goal:

Extract a **deep red/burgundy colorant** rich in **anthocyanins** that matches the intensity, stability, and clarity of synthetic FD&C Red No. 3 or Red No. 40.

# **Method: Cold Acidified Aqueous Extraction**

#### Materials:

- Fresh or dried sorrel calyces
- Distilled water
- Citric acid (or lemon juice)
- Fine mesh strainer or cheesecloth
- Clean glass jars or stainless-steel container
- Food-safe preservative (optional: potassium sorbate)
- pH test strips (optional for standardization)

### **Step-by-Step Extraction Procedure:**

### 1. Preparation

- Wash fresh calyces thoroughly to remove dust/debris.
- Use 100g of dried or 300g of fresh sorrel for every 1 liter of water.

## 2. Acidified Soaking

- In a non-metallic container, mix:
  - 1L distilled water
  - o 1.5–2g citric acid (pH adjusted to ~3.0–3.5)
- Add sorrel calyces.
- Cover and let soak for 24–36 hours at cool room temperature (~18–22°C).
- Stir 2–3 times daily for even extraction.

### 3. Filtration

- Strain the liquid using a fine sieve or cheesecloth.
- Repeat filtration for clarity (double-filter if needed).

## 4. Concentration (Optional)

- If a **stronger pigment** is desired, gently reduce liquid via **low-heat simmering** (not boiling) for 15–20 minutes.
- Do **not exceed 60°C**, as heat degrades anthocyanins.

#### 5. Preservation

- Add **0.1% potassium sorbate** (1g per liter) if the extract will be bottled and stored.
- Store in **amber glass bottles** at 4–8°C.

## **Resulting Product:**

- A vibrant, pH-sensitive red extract
- Turns purple/blue in alkaline conditions
- Ideal for beverages, sauces, cosmetics, soaps

## **Quality Tips:**

- Maintain acidic pH (~3.0) to stabilize the red color.
- Use **low-oxygen processing** if possible, to prevent oxidation.
- Add a small amount of glycerin or ascorbic acid for antioxidant support in cosmetic use.

### **Shelf Life:**

Refrigerated: 4–6 weeks

• Frozen: 3–6 months

Dried (powdered extract): up to 1 year

## **Developed by Quality Solutions Limited (QSL)**